

USER MANUAL – LED Badge

1. Function

The badge can store up to 8 messages. Each message can contain up to 250 characters. Each message can be set to have its own speed and display mode setting. It supports ASCII character set. There are 6 different scrolling modes: Right to left, flash then right to left, bottom to top, top to bottom, flash mode without movement and freeze mode without movement. The badge has 8 different scrolling speeds and luminescence settings. All ASCII characters are split into 4 groups: upper case, lower case, digital and symbol. You may switch between these segments when inputting message.

2. Buttons

- a. Enter
- b. Up
- c. Down

3. Operations

- a. To turn “on” the unit, press “enter.”
- b. To turn “off” the unit, press and hold “enter.”
- c. While “on,” press “enter” to enter the menu which includes: Select input, speed, luminescence, move, flash then move, scroll up, scroll down, flash and freeze. You can choose the item or enter the submenu by pressing “enter.” You can also return to playback by holding “enter” or highlight the item by pressing “up” or “down.”
- d. In SELECT submenu, press “up” or “down” to choose a message to playback, press “enter” to confirm the selection.
- e. In INPUT submenu, you may input the message content here. Press “up” or “down” to select the next or last character. Hold “up” or “down” to switch to the next or last character group. Press “enter” to add the current character to the current message, and hold “enter” to end input
- f. SPEED and LUMINESCENCE submenu: press “up” or “down” to choose scrolling speed or luminescence. Press “enter” to confirm the selection.
- g. Press “enter” to select MOVE, FLASH THEN MOVE, SCROLL UP , SCROLL DOWN, FLASH, FREEZE menu item for the scrolling mode of the current message.

4. Attaching to clothing

The metal plate on the back of the badge is fixed via two strong magnets. Slide the magnet clip to open it. Place the badge on the outside of the clothing and the magnet clip on the inside of the clothing. The magnets will hold the badge in place.

CAUTION

Always slide the magnetic clip to open it. Forcing to pull it open may cause damage to the clip.